

*Here are some common problems on the Chromebooks and some ways to help get them fixed. Please reach out to your child's teacher if you have other questions.*

**My Chromebook won't turn on.**

- Make sure it's plugged in and charging (you should see a light turn on next to the charging port), then try turning it on again. Sometimes you need to wait.

**I can't connect to the internet.**

- Make sure you are on the correct wi-fi network, and make sure the password is correct
- See if other devices (a phone or tablet, or another computer) will connect to the same. network. Try connecting the Chromebook to another network if one is available.
- Restart the Chromebook and try to connect again.

**I can't sign in.**

- Make sure you're using the correct email and password. Emails should end in "@met.lhascholars.net" and passwords can be double checked with your scholar's teacher.
- Make sure you're connected to the internet first.

**The sound won't work.**

- Make sure the volume is turned up.
- If you are using headphones, make sure the headphones are plugged in all the way and the jack is not broken. Try using other headphones or normal sound.
- If this doesn't work, unplug the headphones and then close the Chromebook's lid. Wait 10 seconds, and then plug the headphones back in and open the Chromebook again

**Something on the keyboard isn't working.**

- Please restart the computer first and see if the keyboard still doesn't work after that
- In the short term, you can use the onscreen keyboard: click the time on the bottom-right corner of the screen, click Settings, and then click Advanced at the bottom of the screen. From there, click "Manage accessibility features" and then click "Enable on-screen keyboard"

**The screen is flipped sideways**

- To rotate your screen, use the keyboard shortcut **CTRL + SHIFT +**
- Do this until the screen is fixed.
- Don't play around with this... it may break the Chromebook!

**The screen is frozen!**

- Hold down the power button to shut the computer down.
- Wait ten seconds, and press the power button again to turn the Chromebook on again.