

# Yealink T33 Quick User Guide



## MAKING A CALL

#### Using the handset:

- 1. Pick up the handset.
- 2. Enter the number and press the **Send** soft key.

#### Using the speakerphone:

- 1. With the handset on-hook, press
- 2. Enter the number and press the Send soft key.

## **ANSWERING A CALL**

Using the handset:

Pick up the handset.

### Using the speakerphone:

Press 🔍 .

# VOLUME ADJUSTMENT



ENDING A CALL Using the handset:

Hang up the handset or press the End Call soft key.

## Using the speakerphone:

Press or the **End Call** soft key.

## **MUTING A CALL**

- Press <sup>W</sup> to mute the microphone during a call.
- Press 🤎 again to un-mute the call.

## REDIAL

- Press to enter the Placed Calls list, select the desired entry, and press or the Send soft key.
- Press twice when the phone is idle to dial out the last dialed number.

## CONFERENCE CALL

- 1. Press the **Conf** soft key during an active call. The call is placed on hold.
- 2. Enter the number of the second party, then press the **Send** soft key.
- 3. Press the **Conf** soft key again when the second party answers. All parties are now joined in the conference.
- 4. Press the **End Call** soft key to disconnect all parties.

Note: You may split the conference call into two individual calls by pressing the **Split** soft key.

## PUTTING A CALL ON HOLD

### To place a call on hold:

Press the **Hold** soft key during an active call.

### To resume the call, do one of the following:

- If there is only one call on hold, press the **Resume** soft key.
- If there is more than one call on hold, select the desired call, and press the **Resume** soft key.

## TRANSFERING A CALL

You can transfer a call in the following ways:

### **Blind Transfer**

- 1. Press the **Trans** soft key during an active call.
- 2. Enter the number you want to transfer to.
- 3. Press the **B Trans** soft key.

### **Attended Transfer**

- 1. Press the **Trans** soft key during an active call.
- 2. Enter the number you want to transfer to, and press the **Send** soft key.
- 3. Press the **Trans** soft key when the second party answers.

## CALL HISTORY

1. Press the **History** soft key when the phone is idle,

press  $\bigcirc$  or  $\bigcirc$  to scroll through the list.

- 2. Select an entry from the list, you can do the following:
  - Press the **Send** soft key to call the entry.
  - Press the **Delete** soft key to delete the entry from the list.



#### DIRECTIONS FOR RECORDING YOUR VOICEMAIL GREETING

- 1. Use any desk phone and dial "9999" (Prompt will say "Please enter your Personal Identification Number", but you are not going to do that now.)
- 2. Press the "#" key
- 3. Enter your 4 digit extension number (Prompt will say "Please enter extension number".)
- 4. Enter your Personal Identification Number (PIN). *This will be in your welcome email from 3CX.*
- 5. Press "9" to go to options
- 6. Press "8" to change your greeting message.
- 7. When prompted press "0" to record new self-identification message and at the end of recording message press "#" to stop the recording.
- 8. Press "0" to save the message.

#### **RETRIEVING VOICEMAILS**

Your voicemails will be sent to your email address, for you to play back.

#### OTHER OPTIONS AVAILABLE

You can manage other voicemail settings using any Desk Phone by dialing "9999". Press "#" and enter your extension. A voice menu system will ask you to enter your Personal Identification Number (PIN) followed by "#". The initial options you are presented with, are the following:

- Dial \* to play your messages.
- Dial "9" to go to options.
- Dial pound "#" to exit.

When you dial "9" for options, the following options will be announced by the voicemail system. Dial the respective numbers to change and update these features:

- Dial \* to play your messages.
- Dialing "1" allows you to change your profile status.
- Dialing "3" allows you to dial a number.
- Dialing "4" allows you to delete all read messages.
- Dialing "5" allows you to change your self-identification message.
- Dialing "6" allows you to play mailbox information.
- Dialing "7" allows you to change your voicemail PIN number.
- Dialing "8" allows you to change your greeting message.
- Dialing "9" allows you to restart the voice menu prompts.
- Dial pound "#" to exit.