

## Setting up Classroom Computer/Brightlinks/Elmo:

1. Monitor/Desktop/Elmo – Power Cable to Wall Outlet

2. Keyboard/Mouse – USB Cable to Back of Computer

3. Phone



Network cable from PC Port to Back of Computer  
Network cable from LAN Port to Network Jack on Wall  
*Powercable not necessary*

4. Trulink (Brightlinks Box)



Powercable to wall  
To Elmo  
To Monitor  
To Brightlinks Wall Plate



6. Brightlinks Wall Plate

From TruLink  
(Brightlinks Box)

5. Elmo



Powercable to wall  
To Trulink (Brightlinks Box)  
To Back of Computer  
To Brightlinks Wall Plate  
To USB Port on Back of Computer

