Cutting board plan of procedures

1) Select stock (1x10x16)
2) Joint one edge of each piece of material.
3) Rip each piece of material to width.
4) Alternate the grain on the pieces and mark alignment with a line. (no rough sides are glued)
5) Set up clamps and pre-adjust to size.
6) Set boards on edge and glue.
7) Snug up clamps making sure boards are flat and aligned with pencil marks.
8) Let dry over night.
9) Remove from clamps and scrape off excess glue.
10) Plane one side part way-flip over and plane the other side smooth.
11) Plane first side smooth. (use as few passes as possible)
12) Joint one edge (Jointer)
13) Rip second edge to width (Table saw)
14) Trim one end (Compound miter saw)
15) Cut to length (Compound miter saw)
16) Layout as per plans.
17) Cut out cutting board using jig saw or table saw.(depending on your plan)
18) File and sand the edges smooth.
19) Router the outside edges. (Edge router)
20) Stamp name and date
21) Final sand with 220 grit sandpaper.
22) Apply two coats of mineral oil- liberally.
23) Fill out self-evaluation sheet.
24) Grade.