MILWAUKEE PUBLIC SCHOOLS
BUILDING OPERATIONS

Lead Dust Cleaning SOP

I. TOILET ROOMS

A. Supplies and Equipment

- Personal Protection Equipment (Tyvek suits, Rubber gloves, N-95 Mask,tyvek shoe covers
- Compress air pump filled with 5L disinfectant solution
- H.E.P.A.vacuum
- Clean towels
- Bucket with wringer and clean/clear water
- Clean mops- at least 3
- Micro fiber floor pad
- Toilet brush.
- Floor scrubber
- Green scubbing pad
- Noble floor vacuum
- Garbage bags

B. Procedures for Cleaning Classrooms / Hallways

1. In a designated area change into Personal Protection Equipment
2. Procede to the closest utility sink and fill both buckets and your compress air pump with 5L solution.
3. Procede to class room and begin on high areas, light fixtures, window ledges, door ledges, cabinet tops, desk tops, table tops, door tops, floors and floor corners. When cleaning is completed, remove HEPA Vac from the area.
4. Bring in bucket filled with solution and towel and clean all horizontal surfaces. When towels begin to appear dirty, change towels and place dirty towels in a garbage bag.
5. Using a new mop, mop floors with clean water and change mop heads half way through completion of room. Let the floor dry.
6. Prepare your Swiffer pole with clean Swiffer Wet Pads and procede to Swiffer the floor areas, changing wet pads often or when pad gets dirty. Place dirty pads in garbage for disposal.

C. Procedure Cleaning Bathrooms / Exposed Concrete Floors

1. In a designated area change into Personal Protection Equipment
2. Procede to the closest utility sink and fill both buckets and your compress air pump with 5L solution.
3. Procede to bathrooms and begin on high areas, using HEPA Vac vaccum all light fixtures, window ledges, door ledges, door tops and flat surfaces. Once cleaning is completed, remove HEPA Vac.
4. Using compress air pump, spray and clean all toilets, urinals and sinks. When cleaning is completed, remove compress air pump from the area and place dirty towels in garbage bag for disposal.

5. Using a bucket of clean water and a clean mop head, place water on the floor area, use floor scrubber and green scrubbing pad, procede to scrub the bathroom floor.
6. After floor has been completely scrubbed in all directions, use Nobles Floor Vac to remove dirty water.
7. Bring in another bucket of clean water and a clean mop head, heavily place clean water on floor area, repeating this procedure twice.
8. Once dry, apply ceramic and concrete sealant to floor area using a microfiber pad, repeating this procedure twice.
9. Let floor dry.

D. Finalizing Procedure

1. Gather all cleaning materials and place by exit door.
2. Return to designated area, place all used towels, used PPE equipment, used floor Swiffers in garbage bag and tie in knot.
3. Notify environmental for removal.
4. Place walkoff sticky pads at all entry points.
5. Exit the building.