Connect your Chromebook to Wi-Fi

To connect to the Internet, use a compatible Wi-Fi network.

Step 1: Turn on Wi-Fi

1. At the bottom right, select the time.

2. Select Not Connected .
Note: If you see your Wi-Fi network name and a signal strength, your Chromebook is already connected to Wi-Fi.
3. Turn on Wi-Fi.
4. Your Chromebook will automatically look for available networks and show them to you in a list.

Step 2: Pick a network and connect

Connect to a secure network

1. Select the secure Wi-Fi network .
2. Type the network password.
3. Select Connect.