## VAN PRE-TRIP

## PRESENTATION



### Pre-trip Form

#### **Section One:**

- Car/van #
- Name
- Month
- Year
- Beginning odometer reading
- Ending odometer reading
- Day of the month

	R		ER'S										41	1	١,						
and the second second second second	7		TO BE T						OF E	ACHI	MON	H				AF		_	 Щ		-0
CHECK (√) WHEN INSPECTION SER	RMED.	WR	<b> (</b> X) <b>W</b>	F	AFFE STEEL	ECTS	ARE	FOU	ND.						1					_	
DRIVER'S NAME:							MOI	NTH:				1				J/	Υ	EAR:			
BEGINNING OF MONTH ODOMETER READIN	G;					END	OF N	IONT	'H OD	OME	TER	READ	ING:			1					
DAY OF THE MONTH:																Т					

Why do we need a pre-trip form with the vehicle at all times?

They act as a sort of due diligence, serving as evidence of a consistent commitment to safety. They show that you **have** properly and timely inspected **your vehicles** and made repairs. They show a commitment to compliance with **the** law.

CHECK (√) WHEN INSPECTION IS PE				T	) BE	TURN	NED I	N AT	THE	END	OF E	PECT ACH I			ORI	M		С	AR	#:	_				_
DRIVER'S NAME:	v u	WILL	, IVI	PAA	(^) ¥\	N ELIV	ucri			NTH:							_			V	EAR:				
BEGINNING OF MONTH ODOMETER READ	INC.	$\overline{}$					_	END			_	OME	TED	DEAL	NINO				_	110	EAR.	_	_		_
DAY OF THE MONTH:	ING:	_		_	_			END	OF I	IONI	H OL	OME	IER	KEA	JING	:							$\overline{}$		_
UNDER HOOD INSPECTION:																									
Engine Oil Level	_			т					_	_	П				_		_	_		_			П	_	_
Coolant Level: Check With Cold Engine	Н	$\vdash$		$\vdash$	$\vdash$	$\vdash$	$\vdash$	Н	Н		$\vdash$	$\vdash$	$\vdash$		-			-	Н	-	$\vdash$		Н		$\vdash$
Belts: Check Tension and Condition	Н	$\vdash$		$\vdash$	$\vdash$	$\vdash$	$\vdash$	Н	Н	_	$\vdash$	$\vdash$	$\vdash$	$\vdash$	_	Н	-	$\vdash$	Н	_	$\vdash$		Н		$\vdash$
Leaks: Gasoline, Oil or Water	$\vdash$	$\vdash$		$\vdash$	$\vdash$	$\vdash$	$\vdash$	Н	Н	-	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	Н	_	$\vdash$	Н	$\vdash$	$\vdash$	$\vdash$	$\vdash$		$\vdash$
WALK AROUND/OUTSIDE INSPECTION:																							Н		
Clean Lights and Glasses	Н			Н	Н	Н					Н		Н		_			_		_			Н		_
Windows, Mirrors and Lights	$\vdash$	$\vdash$		⊢	$\vdash$	$\vdash$	$\vdash$	Н	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	Н	_	$\vdash$	$\vdash$	$\vdash$	$\vdash$		$\vdash$		$\vdash$
R&L Headlights-Hi/Lo Beam	$\vdash$	$\vdash$	$\vdash$	⊢	⊢	$\vdash$	$\vdash$	Н	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	_	Н	-	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	Н	$\vdash$	$\vdash$
*	⊢	$\vdash$	$\vdash$	⊢	⊢	$\vdash$	$\vdash$	Н	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	_	Н	_	$\vdash$	$\vdash$	$\vdash$	⊢	$\vdash$	$\vdash$		$\vdash$
R&L Turn Signals R&L Flasher Warning Lights	⊢	$\vdash$		⊢	⊢	$\vdash$	$\vdash$	Н	$\vdash$	$\vdash$	$\vdash$	$\vdash$	Н	$\vdash$	_	Н	_	$\vdash$	$\vdash$	$\vdash$	⊢	$\vdash$	Н		$\vdash$
	⊢	$\vdash$		⊢	⊢	⊢	$\vdash$	Н	$\vdash$	$\vdash$	⊢	$\vdash$	H	Н	_	Н	_	$\vdash$	H	_	⊢	H	$\vdash$		
R&L Parking Lights	⊢	$\vdash$		⊢	⊢	$\vdash$	H	Н	$\vdash$	H	⊢	$\vdash$	H	Н	_	Н	_	H	H	H	⊢	H	$\vdash$		$\vdash$
Fire Extinguisher	_			_	_	_				_			_	_	_					_	_		ш		
UNDER THE VEHICLE INSPECTION:																									
Loose Parts	⊢	<u> </u>		⊢	⊢	⊢	_	Ш		$\vdash$	<u> </u>	$\vdash$	⊢	$\vdash$	_	Н		_	$\vdash$	_	⊢	_	Ш		_
Front Tires: Condition & Inflation	╙	<u> </u>		┞	┡	_	_	Ш	_	_	<u> </u>	_	_	_	_	Ш	_	_	_	_	┡	_	Ш		_
Front Wheels:	ᆫ	_		╙	╙	╙	_	Ш	$\vdash$	$\perp$	_	lacksquare	╙	ш	_	Ш	_	_		_	╙	Ш	Ш		_
Lug Nuts	L			╙	╙	╙		Ш		$\perp$	_		Ш			Ш				_	╙		Ш		
Leaks	L			┖	╙	┖															╙		Ш		
Rear Tires: Condition & Inflation	L			┖	L																┖		Ш		
Rear Wheels:	L			L																			Ш		
Lug Nuts																									
Leaks																									
Exhaust: Leaks or Damage																									
General Outside Appearance																									
CHECK FROM DRIVER'S SEAT:																									
Start Engine, Look & Listen for Trouble	П			Г	Г	П		П		П	П	Г							П		П		П		П
Signs																									
All Instrument Panel Gauges	Г			Г	Г																Г		П		
Horn	Г			Г	П	П	П				П	Г	П		П						Г	П	П		
Defroster & Heater Blowers	Г			Г	Г	Г		П				Г	Г			П					Т	П	П		$\Box$
Windshield Wipers & Washer	Г			Г	Т	Г	Г					Г	Г		П	П			П		Т	П	П		П
Mirrors: Exterior & Interior	г			Т	$\vdash$	$\overline{}$	$\vdash$				$\vdash$				$\overline{}$							П	П		$\overline{}$
Brake Pedal: Height & Feel	г			Т	$\vdash$	$\vdash$	$\vdash$				$\vdash$	$\vdash$	$\vdash$		$\overline{}$			$\vdash$		$\overline{}$	$\vdash$	Т	П		$\overline{}$
Parking Brake: Release & Reset	П			Т	Т		П					Т	Т					$\vdash$	Т		$\Box$		$\sqcap$		
Service Sticker (miles & date)	Н	$\vdash$	$\overline{}$	$\vdash$	$\vdash$	$\vdash$	$\vdash$				$\vdash$	Т	Т	$\vdash$	$\overline{}$	П		$\vdash$	Т	$\overline{}$	$\vdash$	$\vdash$	П		$\vdash$
FINAL CHECK AS YOU MOVE VEHICLE:																									
Seat Belt Fastened	т		Т	т	т	т	т	Т			Т	т	т	т	_		_	т	т		т	т	П	_	$\overline{}$
Brakes: Stop & Hold	Н		$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$			$\vdash$	$\vdash$	$\vdash$	$\vdash$	-	Н	-	$\vdash$	$\vdash$	$\vdash$	$\vdash$		Н		$\vdash$
Steering Feels OK, Uhusual Noises	Н		$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$			$\vdash$	$\vdash$	$\vdash$	$\vdash$	-	Н	_	$\vdash$	$\vdash$	-	$\vdash$		Н		$\vdash$
Transmission Shifts OK	$\vdash$		-	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$			$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	Н	_	$\vdash$	$\vdash$	$\vdash$	$\vdash$		Н		$\vdash$
All Gauges CK	Н		-	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$			$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	Н	_	$\vdash$	$\vdash$	$\vdash$	$\vdash$	$\vdash$	Н		Н
REPAIR REQUESTED:																							Н		
INTIAL OF PERSON SUBMITTING																									
PRE-TRIP				l									l												
	۲	S	UBMI	T TO	TRA	NSPO	ORTA	TION	DEP	ART	MENT	ONL	AST	DAY	OF I	NON.	TH								
REMARKS.																									
SIGNATURE:													_	DA	TE:										

#### 8VAC20-70-380. Pre-Trip Safety Inspection.

Prior to the initial transporting of children each day, the drivers of school and activity buses shall perform a daily pre-trip safety inspection of the vehicle. The items checked and recorded shall be at least equal to the pre-trip inspection procedure in the Preventive Maintenance Manual for Virginia School Buses (September 2012) issued by the Department of Education.

# Under the Hood Inspection

#### **Check:**

- Coolant Level
  - Check with cold engine




#### UNDER HOOD INSPECTION: Engine Oil Level

Coolant Level: Check With Cold Engine Belts: Check Tension and Condition Leaks: Gasoline, Oil or Water

# Under the Hood Inspection

#### **Check:**

 Belts for tension and condition




#### UNDER HOOD INSPECTION: Engine Oil Level

Coolant Level; Check With Cold Engine Belts: Check Tension and Condition Leaks: Gasoline, Oil or Water

# Under the Hood Inspection

#### **Check:**

- Leaks -
  - Gasoline, oil or water



UNDER HOOD INSPECTION:													
Engine Oil Level													
Coolant Level: Check With Cold Engine													
Belts: Check Tension and Condition													
Leaks: Gasoline, Oil or Water	7												

# Walk Around/Outside Inspection

#### **Windows**

- Mirrors
  - No cracks
- Light Lens
  - No cracks





WALK AROUND/OUTSIDE INSPECTION:														
Clean Lights and Glasses														
Windows, Mirrors and Lights	V													
R&L Headlights-Hi/Lo Beam														
R&L Turn Signals														
R&L Flasher Warning Lights	Г													
R&L Parking Lights Fire Extinguisher														
Fire Extinguisher											$\Box$		$\Box$	

# Walk Around/Outside Inspection

#### **Right & Left:**

- Headlights HI/LO Beams
- Turn Signals
- Flasher/warning lights
- Parking Lights





WALK AROUND/OUTSIDE INSPECTION:														
Clean Lights and Glasses														
Windows, Mirrors and Lights		1												
R&L Headlights-Hi/Lo Beam	7													
R&L Turn Signals	V	5												
R&L Flasher Warning Lights														
R&L Parking Lights	V													
Fire Extinguisher														

## Walk Around/Outside Inspection

**Fire Extinguisher** 

ጼ

Gauge

(should be in the green)



Anytime the fire extinguisher reads 'recharge', it must be taken to the Service Window for exchange.

Same for 'overcharge', must be taken to the Service Window for exchange. Fire extinguisher could be very explosive at the overcharged state.

•		-	-				_							
WALK AROUND/OUTSIDE INSPECTION:														
Gean Lights and Glasses														Г
Windows, Mirrors and Lights														
R&L Headlights-Hi/Lo Beam														Г
R&L Turn Signals														Г
R&L Flasher Warning Lights	П													Г
R&L Parking Lights														Г
R&L Parking Lights Fire Extinguisher														Г
	1													



## Under the Vehicle Inspection

- Loose Parts
- Front Tires:
  - Condition & Inflation
- Front Wheels
  - Lug Nuts
  - Leaks
- Rear Tires
  - Condition & Inflation
- Rear Wheels
  - Lug Nuts
  - Leaks
- Exhaust Leaks/Damage
- General Outside Appearance

Front & Rear Tires





**Lug Nuts & Leaks** 





JNDER THE VEHICLE INSPECTION:												
Loose Parts												Г
Front Tires: Condition & Inflation												Т
Front Wheels:												Γ
Lug Nuts												Т
Leaks												Γ
Rear Tires: Condition & Inflation												Т
Rear Wheels:												Τ
Lug Nuts												T
Leaks												Т
Exhaust: Leaks or Damage												T
General Outside Appearance												T

### **Check from the Driver's Seat**

#### **Check:**

- Start engine, look & listen for trouble signs
- All instrument panel gauges
- Horn
- Defroster & heater & blowers
- Windshield wipers & washer
- Mirrors: exterior & interior
- Brake Pedal: height & feel
- Parking Brake: release & reset
- Service Sticker: miles & date

#### Mirrors: exterior & interior



#### **Brake pedal**



#### All instrument panel gauges



#### Defroster & heater blowers



#### Defusites O bastos blasses



Windshield wipers & washers

Parking brake



Horn

#### **Services sticker**



#### CHECK FROM DRIVER'S SEAT:


Start Engine, Look & Listen for Trouble Signs

All Instrument Panel Gauges Horn

Defroster & Heater Blowers Windshield Wipers & Washer

Mirrors: Exterior & Interior
Brake Pedal: Height & Feel

Parking Brake: Release & Reset Service Sticker (miles & date)



### Final Check as you move the vehicle

Steering feels OK, no unusual noises

**Transmission shifts OK** 

#### **Check:**

- Seat belt fastened
- **Brakes: stop & hold**
- **Steering feels OK, no unusual** noises
- **Transmission shifts OK**
- All gauges OK

**Seat Belt Fastened** 



All gauges OK







,	. 4	<b>.</b>		4			ı								
FINAL CHECK AS YOU MOVE VEHICLE:															
Seat Belt Fastened	7														
Brakes: Stop & Hold						П									П
Steering Feels OK, Unusual Noises					T										Т
Transmission Shifts OK															
All Gauges OK															Т

### Final Check as you move the vehicle

#### **Hydraulic Brake Check**


 Pump the brake pedal three times, then hold it down for five seconds. The brake pedal should not move (depress) during the five seconds.

#### **Hydraulic Brake pedal**



This section is not included on the Car Driver's Daily Pre-Trip Inspection Form. Please make note on the form that your hydraulic brakes system is working correctly.

### Before turning in pre-trip form, make sure all boxes are completed.



Submit to Transportation Department on the last day of month

Repair Requested - Service request slip must be filled out.

## Click the link below to complete the Van Pre-Trip Quiz and then click submit.

### **VAN PRE-TRIP QUIZ**

