

# Full Seating Chart


Total Seats: **551**

Apron 1/2: **547**

Apron Full: **526**

When the apron is in the down position, all seats are available. When the apron is at half, row A is modified. When the entire apron and thrust are in full, rows A & B are removed.

 Denotes a removable seat to accommodate patrons in wheel chairs.

 To maintain six feet between seated persons, only these seats can be used or assigned.

