

T-Mobile T9 Hotspot



1. Plug the cable into an outlet and into the USB jack on the hotspot.
2. Press and hold the power button for 3 seconds until the “welcome” shows in the menu window.
3. Use the power button to scroll through the menu window until you see the username and password.
 - Write down the username and password.
4. Turn on your Chromebook.
5. You will receive a “network not available” screen since no internet service is connected.
6. Click the “select a network” dropdown field or scroll through the different network options until you find the username that matches the username in the hotspot menu.
7. Enter the password you wrote down previously.
8. Press enter, and you will be connected to the internet.

Charging Your Hotspot (All models of hotspots)

The hotspot contains a battery and can function for several hours between charges. The hotspot can be used while charging. If possible, place the hotspot near a window for better reception of the T-Mobile wireless signal.

How to Charge

- Insert the small end of the cable into the hotspot and the large end of cable into the charger.
- Plug the charger into a wall power outlet.

Returning Your Hotspot (All models of hotspots)

Your hotspot, cable, and charger should all be returned when you graduate or transition from your school so that another student can use it.

Hotspots will be deactivated when:

- The hotspot is turned in by a student
- A student leaves the district and has not returned their hotspot
- The hotspot is reported lost or stolen
- The hotspot is reported as inactive or not for in use by T-Mobile for an extended period
 - Make sure to use your hotspot!