

Windows 7 Driver Solutions

At this time, a full feature Windows 7 driver solution is not available for your product. However, a compatible print driver solution for your product is included with the Windows 7 operating system. There is no need to download any additional software.

Follow the steps in this document to identify the print driver that is compatible with the product, install the driver, and then configure it in Windows 7. When this driver is installed, you can use the basic functions of the product.

Install and configure a compatible driver:

Follow these steps to install and configure the driver that is compatible with the product.

Step one: Determine the appropriate compatible driver

Use the following list to find the driver that is compatible with your product.

ProductAlternate driver

Deskjet 3320, 3325, 3420 and 3520 Deskjet 3600 *

Photo smart 7600 series Deskjet 5600

Deskjet 5850 Deskjet 5600

Photo smart 130, 145, 230 and 245 Photo smart 330 *

Photo smart 7350 and 7550 Deskjet 5550

Deskjet 6122 and 6127 Deskjet 990c *

Deskjet 3820 Deskjet 970cse *

Deskjet 656 Deskjet 660c *

Business Inkjet 1100d Business Inkjet 1000

Business Inkjet 1100dtn Business Inkjet 1000

Deskjet 9300 Deskjet 1220c *

Deskjet 9650, 9670, 9680, 9680gp Deskjet 9800

* Available only through Windows Update.