

Model	Part Description	Part Number	Price	On Hand
ALL MODELS	11.6" LCD SCREEN	FGF20	\$38.95	
G3 (3180)	AC ADAPTER	GTTTT	\$19.95	
G3 (3180)	AUDIO BOARD WITH CABLE	7YYXC	\$9.95	
G3 (3180)	BATTERY (51KD7)	Y07HK	\$69.95	
G3 (3180)	BATTERY CABLE	8367J	\$7.95	
G3 (3180)	BOTTOM CASE	YJDF3	\$12.95	
G3 (3180)	CAMERA	F08KG-3180	\$6.95	
G3 (3180)	DC-IN POWER JACK	XNJ46	\$6.95	
G3 (3180)	HINGE COVER SET	DELL-3180-HINGECOVERSET	\$8.95	
G3 (3180)	LCD BEZEL	0P37K	\$15.95	
G3 (3180)	LCD TOP COVER	5HR53	\$24.95	
G3 (3180)	LCD VIDEO CABLE	P1NX2	\$9.95	
G3 (3180)	MOTHERBOARD 4GB	1TX65	\$67.95	
G3 (3180)	PALMREST WITH KEYBOARD & TOUCHPAD	VKOVCA-CA	\$44.95	
G3 (3180)	SCREW SET	CB113180-SCREWS	\$6.95	
G3 (3180)	SPEAKER SET	DW9G6	\$2.95	
G3 (3180)	TOUCHPAD CABLE	CPFC1	\$24.95	
DELL 3100	AC ADAPTER	MVPDV	\$36.95	
DELL 3100	BATTERY (JPFMR)	16DPH	\$69.95	
DELL 3100	BATTERY CABLE	9MJG6	\$8.95	
DELL 3100	BOTTOM CASE	2RY30	\$19.95	
DELL 3100	CAMERA	G4JK9	\$9.95	
DELL 3100	LCD BEZEL	6C2J6	\$17.95	
DELL 3100	LCD TOP COVER	34Y4Y	\$24.95	
DELL 3100	LCD VIDEO CABLE	V11RY	\$9.95	
DELL 3100	MOTHERBOARD 4GB	GD6HC	\$119.95	
DELL 3100	PALMREST WITH KEYBOARD & TOUCHPAD	9X8D7-CA	\$49.95	
DELL 3100	SCREW SET	DEL3100-SCREWS	\$5.95	
DELL 3100	SPEAKER SET	MFX68	\$4.95	
PRICES CURRENT AS OF 05/05/2022				