

## **Proper Fueling Procedure**

### **Propane**

- 1 Swipe round fuel fob on key ring
- 2 Enter the pump number press enter
- 3 Enter the odometer reading press enter. Please try to be as accurate as possible.
- 4 Swipe your badge. You should now be prompted on the screen to refuel.
- 5 Open Fuel door remove dust cap and press nozzle on. Pull back the black lever on pump nozzle to lock in place.
- 6 Press start valves will now open please be patient when fueling at the service center as it takes a minute for the propane to start pumping. Please allow a little time before calling the garage to say it's not working.
- 7 Never walk away stay right there at the pump the entire time you are fueling.
- 8 After finishing fueling make sure to press the stop button and wait for valves to close then remove the nozzle.
- 9 Make sure to replace the dust cap and shut the fuel door. Just a reminder if the fuel door is open your engine will not start up. If you have finished fueling and your bus does not start check the fuel door before calling the garage.

### **Diesel and Gasoline**

- 1 Swipe round fuel fob on key ring
- 2 Enter the pump number press enter
- 3 Enter the odometer reading press enter. Please try to be as accurate as possible.
- 4 Swipe your badge. You should now be prompted on the screen to refuel.
- 5 Remove fuel cap and insert the nozzle begin fueling.
- 6 Never walk away stay right there at the pump the entire time you are fueling.
- 7 After you finish fueling replace nozzle and fuel cap.