

Set #20	General Purpose (Adjustable US/DS from back wall to traveler)	Contents:
Set #19	Traveler (Dead Hung - 44" off back wall)	
Set #18 (38*)	4th Electric (8 circuits in two drop boxes: dimmers 71-78)	
Set #17 (35*)	Border (7' off back wall)	
Set #16 (32*)	General Purpose (9' off back wall)	Contents:
Set #15 (31*)	3rd Leg Set (21.5' off back of proscenium wall)	
Set #14 (28)	3rd Electric (12 circuits - true electric with pigtails along batten: dimmers 59-70)	
Set #13 (26*)	General Purpose	Contents:
Set #12 (23*)	Border	
Set #11 (20*)	General Purpose	Contents:
Set #10 (19*)	2nd Leg Set (13.5' off back of proscenium wall)	
Set #9 (16*)	2nd Electric (8 circuits in two drop boxes: dimmers 51-58)	
Set #8	General Purpose (Dead Hung)	Contents:
Set #7 (12*)	Traveler (chained for easy transfer)	
Set #6 (10*)	Border	
Set #5 (8*)	Projection Screen (short cables - can't fly batten to floor)	
Set #4 (7*)	1st Leg Set (5.5' off back of proscenium wall)	
Set #3 (5*)	1st Electric (8 circuits in two drop boxes: dimmers 43-50)	
Set #2	Grand (Dead Hung - 28" off back of proscenium wall)	
Set #1 (1*)	Grand Border	

NOT DRAWN TO SCALE!

*=Line Set # engraved on label plates.

↓ House ↓

Notes: Grand and Travelers protrude 12" past proscenium wall when fully open. Deck Pulleys for Grand and Travelers are mounted 51" off stage of the edge of the proscenium. Legs are mounted on rails and can be pulled in to leave a ~4' opening between them at center stage.