


How To: Turn on Closed Captioning on Projectors

In order to watch VHS tapes or DVDs with Closed Captioning, the Closed Captioning must be turned on on the projector.

- Select “Menu” on the Projector Remote



- Go to Extended
- Go to Closed Caption
- Select CC1



Please note that the closed captioning will not begin until the menu is closed.