

CLEANING AND DISINFECTING GUIDE FOR CHROMEBOOKS

Chromebooks can be cleaned by wiping all surfaces, including keyboard and screen:

1. Power off the device.
2. Remove accessories, plug-ins, and power supply.
3. Use a soft cloth or microfiber towel. Do not spray the device with disinfectant.
4. Wet the cloth or towel with an approved cleaner until damp but not soaking wet. Clorox pre-moistened wipes can be used as well, just make sure they are not too wet before you begin.
5. Wipe the entire Chromebook including the keyboard and screen so that the surfaces are wet, but do not allow liquid to stand or pool on the device or let it seep in under the keys or edges of the screen.
6. Leave the Chromebook open and allow to air dry to disinfect.
7. If screen has any residue after disinfection, you can wipe again with damp towel and then dry with dry towel to clear the residue.
8. Surfaces must remain wet for the time allotted below for proper disinfection

PLEASE DO NOT:

- Submerge in water or other liquid
- Run under the faucet
- Allow approved cleaning product to get in to any ports
- Use coarse paper towels, cloths, or scrubbers. Coffee filters are usually ok to use.
- Do not scrub or press too hard on the screen.

Acceptable cleaning products: **DO NOT USE PRODUCTS THAT CONTAIN BLEACH or HAND SANITIZER**

As always these products should not be used by children without adult supervision and proper handling

- 70% isopropyl alcohol – Dries and disinfects in 30 seconds
- 3% hydrogen peroxide – Dries and disinfects in 2 minutes
- Clorox Disinfecting Wipes – Dries and disinfects in 4 minutes

<https://www.epa.gov/pesticide-registration/list-n-disinfectants-use-against-sars-cov-2>

<https://www.americanchemistry.com/Novel-Coronavirus-Fighting-Products-List.pdf>