

The student devices require a full shutdown when moving from one location to another. This includes...

- a. Going from home to school.
- b. Going from school to home.
- c. Any time you leave one location to go to another with the possibility of using your Dell Latitude 3310 Student Laptop.

This process relieves the issue of not being able to connect to Wi-Fi when the device is opened in a new location.

To accomplish this, before you move to your next location, please follow the 3 steps to the right...

In this order, click...

- 1. Start Menu
  - 2. Power
  - 3. Shut Down
- Every time you are done using the machine wherever you are.

