

About your Hotspot




1. Menu button
2. Signal status icon
3. Network mode icon
4. Wi-Fi signal icon
5. Unread message icon
6. Battery icon
7. Power button
8. USB Type-C Port
9. Battery cover




Powering On the Hotspot

- To turn it **on**, press and hold the **Power** button for **2** seconds.
- To turn it **off**, press and hold the **Power** button for **3** seconds.
- To **wake** the Mobile Hotspot display, press and release the **Power** button.

The Home Screen



If you have unlimited data:




IMPORTANT!
Charge the battery completely before you connect your computer to your Mobile Hotspot.




Setting Up the Connection

1. Click the **WiFi** icon in the system tray on your device.
2. Search for the wireless network connection named **"Verizon-RC400L-XX"**.
3. Click **"Connect"**.
4. Enter the **Password**.



Getting the Password

The Password can be found by pressing the **MENU** button and selecting the **2.4GHz** WIFI info or **5GHz** WIFI Info screen. The password is displayed next to the lock icon.



IMPORTANT!
Charge the battery completely before you connect your computer to your Mobile Hotspot.

Acerca de tu Hotspot




1. Botón de menú
2. Icono de estado de la señal
3. Icono de modo de red
4. Icono de señal de WiFi
5. Icono de mensaje no leído
6. Icono de batería
7. Botón de encendido
8. Puerto USB tipo C
9. Ensenada de la batería


Encendido el Hotspot

- Para encenderlo, mantenga presionado el botón de encendido durante 2 segundos
- Para apagarlo, mantenga presionado el botón de encendido durante 3 segundos
- Para activar la pantalla del punto de acceso móvil, presione y suelte el botón de encendido

La pantalla de inicio



If you have unlimited data:



¡IMPORTANTE!
Cargue la batería por completo antes de conectar su computadora a su punto de acceso móvil


PEAR
Educational



LAND
Technology



Configurar la conexión

1. Haga clic en el icono de WiFi en el bandeja del sistema en su dispositivo.
2. Busque el inalámbrico conexión de red nombrada "Verizon-RC400L-XX".
3. Haga clic en "Conectar".
4. Introduce la contraseña.



Obtener la contraseña

La contraseña se puede encontrar presionando el botón MENÚ y seleccionando la información de WIFI de 2.4GHz o la pantalla de Información de WIFI de 5GHz. La contraseña se muestra junto al icono de candado



¡IMPORTANTE!
Cargue la batería por completo antes de conectar su computadora a su punto de acceso móvil.