


Using the Whiteboard feature on SMART Board 6000S Series


1. Go to the lower left of the SMART Board to access the power button.




2. The power button will be illuminated red. Push the power button and it will illuminate white along with the other buttons.



3. The SMART Board iQ Homescreen will now appear.



4. Tap the tile labeled Whiteboard.




5. The Whiteboard will now appear.




6. There are Black and Red Pens on the lower center of the board.




7. There is a Pen tray on the upper left of the board as well.



8. The Pens will write in the color they are labeled with



9. You can erase using the erasers mounted to the lower center of the board, or with the eraser on the back of each pen.



If you still require assistance, please open a help Desk Ticket
<http://helprequest.centralislip.k12.ny.us/helprequest>