

Pairing the BenQ Remote to the BenQ Panel

Introduction

The BenQ Panel is equipped with a wireless remote to help facilitate instruction while using the board. In the event the remote becomes unpaired, this guide will assist in pairing the remote control back to the BenQ Panel.

Getting Started

1. Locate the **BenQ remote** on the back of the BenQ Panel. Looking at the back of the board, the remote will be velcroed to the top left-hand side.



Pair BenQ Remote

1. Locate the **USB receiver** on the back right-hand side of the BenQ Panel.




2. Point the **remote control** near the **USB receiver** on the back of the BenQ Panel.



3. Press the **V-** and **BLANK** buttons at the same time, and the indicator light will **start flashing**.




4. Pairing is complete once the **indicator has stopped flashing**.



5. To check remote function, point remote towards board and enable the pointer. If the red dot (pointer) appears and moves when the remote is moved, the remote has been paired.

Pairing the BenQ Remote to the BenQ Panel

BenQ Remote Quick Reference



BenQ