

## CHARGING AND CARING FOR YOUR BATTERY:

The light on the charger will tell you some information about the battery itself. The table below explains this in detail.

CHARGER LIGHT	DESCRIPTION
Flashing Orange	Battery is waiting to charge. Battery needs to cool down or warm up before charging.
Steady Orange	Battery is <b>reconditioning</b> and will then begin charging normally.
Solid Red	Charging.
Flashing Red	<b>Bad battery.</b> The battery is not chargeable.
Flashing Green	<b>&gt;90% charged.</b> Battery charging is nearly complete.
Solid Green	<b>100% charged.</b> Battery is fully charged and ready for use.
Flashing Alternating Red and Green	Battery has reached the end of its service life. Replace.

## SOME OF THE TONES YOU MAY HEAR:

TONE	DESCRIPTION
Talk Permit Quick chirping sound (dah dah dit)	Your transmission can proceed and will be broadcast. You must wait until the talk permit sound is finished.
Bonk Long, medium tone (boooooooooonk)	You can't talk. Someone may be using the talkgroup you wish to use. Wait until they are finished.