

MISD Device Prices

Prices are subject to change.

Last update: 8/7/2024

ACER C871	
Bezel	\$4
Camera	\$11
Camera Cable	\$6
Left / Right Hinge (ea)	\$9
Keyboard	\$30
LCD Screen	\$73
Mouse/TouchPad	\$23
Top Cover	\$15
Top Half Complete	\$120
USB-C Board	\$12
Full Replacement of Unit	\$273

MISCELLANEOUS	
NutKase Folio Case	\$24
Charger	\$20
HotSpot Replacement	\$40
HotSpot Charger	\$20

HP CHROMEBOOKS			
	G8	G9	Touchscreen
Battery	\$23	\$23	\$23
Bezel	\$22	\$22	\$22
Camera	\$9	\$13	\$13
Camera Cable	\$16	\$13	\$13
Daughterboard	\$23	\$21	\$21
Hinge Cover	\$9	\$9	\$9
Hinge Set	\$10	\$9	\$9
Keyboard	\$49	\$55	\$55
LCD Screen	\$50	\$50	\$55
Motherboard	\$106	\$129	\$129
Top Cover	\$27	\$32	\$32
Video Cable	\$13	\$16	\$16
Full Replacement	\$273	\$273	\$289

OTHER DEVICES	
iPad Replacement	\$300
iPad Case	\$50
HP x360 Teacher Laptop	\$940
HP x360 Screen Replacement	\$285