

One-page tips for using the ReaderPen

Updated 2022 August

Mode overview

Once you turn on the ReaderPen, you're asked to select one of several modes. These are:

Text Reader: Enables the Pen to read aloud scanned text.

Dictionary: Allows a user to scan single words and provides definitions.

Scan to file: Allows a user to save scanned text to the ReaderPen, allowing for an upload of that file to personal computer via micro-USB cable.

Recorder: Allows a user to record voice memos.

Scanning to a computer

The ReaderPen is capable of scanning physical text to one's personal computer – think of it as a digital highlighter. To do this:

1. Turn on the ReaderPen.
2. Connect the ReaderPen to your computer via the micro-USB cable included in the kit.
3. The device presents the user with three options: Keyboard, U-Disk, and Charging. Select "Keyboard."
4. Open a word processor like Microsoft Word, or whichever program you usually use to take notes.
5. Begin scanning!

Like the "Keyboard" mode implies, your computer interprets the ReaderPen as a newly connected keyboard, from which it will receive character inputs. Note that you can still use your computer's actual keyboard simultaneously.

Switching to left-handed mode

The ReaderPen can switch between right-handed and left-handed configurations. If you hold the Pen with your dominant hand and find that the text on the device's screen is upside down, it's likely set to the opposite configuration for you. To change this:

1. Go to the Settings menu (this is found below the menu "Recorder")
2. Scroll down to Left/Right Handed and select the correct orientation

For more detailed information on using the ReaderPen, please consult the Quick Start Guide included with the device.