

Step 1: Charge the Battery

First, fully charge the battery.
Be sure to use the charger that came with the device.

Step 2: Turn on the Device

Press and hold the power/menu button for 3 seconds



Step 3: Connect to the Device

1. On your Chromebook (or another Wi-Fi capable device), search for available Wi-Fi networks
2. Select the Hotspot Wi-Fi Name (SSID): **MPSHS00XXXXX**
3. Enter the password: **MPS*Remote2020!**

Type this password exactly as you see it, including uppercase and lowercase letters.

Note: With the device, you can connect a total of 8 devices to the internet.

Learn more about the Power Button

Turn the Device "Off"

Press and hold the power button until the "Goodbye" message appears.

Display Wake-Up

When the display is off (sleep mode), quickly press the power button to wake up the display.

Info Display

When the display is on, press the power button quickly to go through the device menu and information.