Promethean

How to Use the Pink Menu Button for ActivConnect OPS-G and ActivConnect G

1. **BACK BUTTON**: The Back button allows you to navigate back to the previous screen.
2. **HOME**: The Home button allows you to quickly return to the home screen.
3. **PROMETHEAN WHITEBOARD APP**: Turn your classroom display into a blank interactive canvas. Use the annotation tools to write or draw, insert images, and more.
4. **SCREEN CAPTURE**: Instantly capture screenshots of anything displayed on your screen. Annotate directly onto the screenshot using the Promethean Whiteboard App and save if you wish.
5. **PROMETHEAN ANNOTATE APP**: Annotate over anything displayed on your screen quickly and easily.
6. **PROMETHEAN TIMER APP**: Launch up to four clocks, timers, or stopwatches simultaneously for classroom management.
7. **PROMETHEAN SPINNER APP**: Randomize elements of your classroom with ease. Choose from six default lists or create your own.

Follow us on Twitter @LearnPromethean, subscribe to our PrometheanVideo YouTube channel, sign up to hear from us, and visit our website to learn more.