

Double check electrical breaker. Reset, wait **1-2 full minutes** before connecting score clocks.

Then try the following for general reboot: :

BASKETBALL: For general reboot:

Function 1, Enter (starts new game)
Function 3, Enter select sport
Function 2, Enter basketball mode
Function 1, Enter (starts new game)

Only use if selecting different sport

VOLLEYBALL

Function 1, Enter (starts new game)
Function 3, Enter select sport
Function 13, Enter volleyball mode
Function 1, Enter (starts new game)

Only use if selecting different sport

If this does not solve the situation, please have Coach email **contact cell number** and **location** of score clock that will be needing a be needing a service call.