



Instructions for DSD laptops at home:


Connect to Wi-Fi before signing into the laptop. Click the network icon in the lower right corner to select a wireless network:



You should see a list of available Wi-Fi networks to choose from. The square "Wi-Fi" button should also be blue to indicate that Wi-Fi is active.



If you have any problems signing in or using the internet, make sure Airplane Mode is not enabled. If you see an airplane icon instead of a Wi-Fi icon, click the airplane and then click the blue *Airplane mode* icon to turn it off.



The power cord for your Cloudbook may include two separate pieces that must be connected. Please attach the two pieces together firmly before using.



If the power cord plug is not properly seated into the power adapter, the power cord will not function.




The power cord plug should be completely inserted into the adapter. It will be a tight fit but this will keep it from disconnecting accidentally. If the device does not appear to be charging correctly, please verify that the plug is securely connected.



Important troubleshooting steps:

1. Reboot first!

If your device isn't working correctly, a reboot should be the first action taken. Click the Start button, then click the power icon and choose *Restart*.



2. Check the battery life

It is essential that this device remain adequately charged at all times. If the battery is too low, the device may stop functioning properly.



3. Let the device sleep at night

When you are done using the laptop, please *sign out and close the lid* to put the device in sleep mode. Make sure the device is plugged into power at night. This lets the device wake up at night to get updates. If the device is powered off, the device won't wake up and updates will not happen.

