


Hagaajinta Hot Spot kaaga

Daar kumbuyuutarkaaga

1. Kumbuyuutarkaaga ama aaladda kale ee Wi-Fi loo suuragaliyay, ka raadi khadadka Wi-Fi ee la heli karo oo xulo magaca khadka (Franklin T9 #####, lambarradu waa 4-ta ugu dambeysa ee IMEI) oo ku yaala gudaha qeybta dambe ee hotspot ka moobilkaaga.
 - ee Windows PC:
 1. Riix dhinaca bidix ee (Khadka) Wireless ka ee shaashada si aad u eegto (khadadka) la heli karo.
 2. Ka dooro SSID liiska khadadka la heli karo
 - ee ka socda Mac koombuyuutar:
 1. Xullo **System Preferences > Network > Airport.**
 2. Riix **Midka Hormarsan si aad uga doorato SSID liiska khadadka la heli karo.**
 3. Ka dooro SSID liiska khadadka la heli karo
 - ee aalada iOS:
 1. Aad **Setinka > WIFI**
 2. Ka dooro SSID liiska khadadka la heli karo.
 - ee aalada Android:
 1. Aad **Setinka >-setinka. WIFI**
 2. Ka dooro SSID liiska khadadka la heli karo.

Device Display



Icons	Description
	5 level signal strength indicators. More bars indicate a stronger signal.
	Networks icon appears depends on which networks connected. (LTE / 3G / Roaming)
	Appears when data is being transmitted between the mobile network and your hotspot.
	Shows the number of connected devices. (1-14 and Max).
	Appears when you have unread messages.
	The bar inside the battery indicates the battery level. When battery power is low, the battery outline blinks.

Button Operation		
	Operations	Actions
	Turn On	Press and hold the button for 3 seconds.
	Turn Off	Press and hold the button until "Goodbye" message appears.
	Display Wake-Up	When the display is off (sleep mode), the first quick press of the button wakes up the display.
	Info Display	When the display is on, press the button quickly to go through the device menu and information.
LED Indicator		
	Colors	Charging Status
	Off	Power off.
	Solid	Power off and connected to a charger.
	Blinking	Power on/Operating normally

T-Mobile (Ileh daaqada LCD) Nooca T9

- Cilidaha xarfaha sirta ah. Haddii uu kaga dhagan yahay istiikir xagga hoose oo aadan heli karin xarfaha sirta ah ee lagu shaqeynayo, kala dul dhufo shaashadda LCD si aad u muujiso xarfaha sirta ah.
- Haddii aadan heli karin chromebook/laabtoob si aad u aqoonsato xarfaha sirta ah ee ka muuqda shaashadda LCD, Dib ugu celi aaladda warshad. Ka bixibatteriga daboolka oo waxaa jira badhanka dib-u-dejinta. Iyada oo kumbuyuutarka daaran yahay (koronta gali bateriga haddii batteriga uu koronto la'aan yahay) xaji badhanka dib u dejinta illaa shaashadda LCD ay ka muujineyso in ay samaynayso dib u dejinta. Xarfaha sirta ah waa la beddeli kara. Xarfaha sirta ah waxay kasoo muuqanayaan shaashada marka aad ku dul dhufatid.
- Isku mid ahaansho la'aanta Khadadka. Isku day inaad u wareejiso aaladda meel ka wanaagsan oo ah “banaanka oo dhaw ah”. Haddii aad arki karto munaaradda ee kuugu dhow, taasi oo ay tahay inaad dhigjisid Hotspot ka, adoo eegaya jihadaas.
- Ciladaha khadka ee waqti kasta dhici kara
 - Isku day inaad ka bixiso bateriga (damista qabaw) oo dib ugu celi
- soo saaritaanka iftiinka cagaaran
 - Bateriga oo jaajar garaysamaya
- Ereyga soo dhaweynta ayaa kor soo fuula marka hotspot ka dab qaadanayo oo uu xiriirismayo
 - Shaashada kore ee shaashada LCD
 - Daaqada calaamadaha 1 - 5 (ugu fiican)
 - LTE (Ugu wanaagsan)
 - Falaaraha Kor/Hoos ee u kala diritaanka Xogta hotspot iyo chromebook
 - Jaajarka Bateriga iyo/ama heerka bateriga
 - Shaashada isticmaalka Xogta
 - Waqtiga wuu Dhamaada, kani wuxuu noqon doonaa taariikhda aad xogtaada dib u cusbooneysiin doonto.
 - Daaqada bar Xogta oo u muuqan doonta inay banaan tahay hadii xogta aan la isticmaalin, way buuxin doontaa marka xogta la isticmaalo. Waxay sidoo kale yeelan doontaa lambar ###.#/20GB Lambarka koobaad waa inta la isticmaalayo kan ugu dambeeyaana waa inta la oggol yahay.
 - Magaca Wifi ga
 - Franklin T9 ####
 - Xarfaha sirta ah:
 - Xaraf iyo lambar la isku daray oo 8 xarfood ah
 - Galitaanka websaytka aalada
- Badhanka korontada
 - Xaji saddex ilbiriqsi si aad u daarto
 - Xaji saddex ilbiriqsi si aad u damiso