

This card is for subscribers with display telephones that use the Norstar Voice Mail interface.

You must initialize your mailbox to receive and store messages.

1. Press on your display telephone.
2. Press (default password) and press **OK** or .
3. Choose a password from four to eight digits long that does not start with zero. Enter your new mailbox password and press **OK** or .
4. Enter your new mailbox password again and press **OK** or .
5. At the tone, record your name in the Company Directory.
6. Press to end the recording. Press to accept the recording.
7. Press to end the session.

Note: If you do not record any personal greetings, your Company Directory name plays to callers who reach your mailbox.

There are three types of Personal mailbox greetings: Primary, Alternate and Personalized.

Is your everyday mailbox greeting. In this greeting include your name, mailbox number and a brief message explaining to callers that you are unable to answer their calls.

Is a special greeting for times when you are away from the office or on vacation.

Up to three Personalized mailbox greetings are available when your company subscribes to Caller ID (CLID) services from your local telephone company.

A Personalized mailbox greeting plays to callers based on the caller's telephone number. CallPilot recognizes the assigned incoming telephone number and plays the Personalized mailbox greeting.

Use the *Mailbox commands* illustration as a guide when you record your greetings.

- Use your handset, not the Handsfree feature.
- Speak clearly and at a pace that is easy to understand.

After you record Primary and Alternate greetings, you must select a greeting to play. If you do not select a greeting, the Primary greeting plays automatically.

If you choose the Alternate mailbox greeting, you are asked whether the mailbox accepts messages. If you choose Y (yes) your mailbox receives messages in the normal way.

If you choose N (no):

- Messages cannot be left in your mailbox.
- The Alternate mailbox greeting takes precedence over all other greetings.

Personalized greetings will be played for up to three specific external telephone numbers instead of the Primary or Alternate greetings.

Use the *Mailbox commands* illustration as a guide when you choose a greeting.

Change your mailbox password every 30 days. Your mailbox password keeps your voice messages private and confidential. Choose an uncommon password (not 1111 or 1234) that is from four to eight digits long and does not start with zero.


Use the *Mailbox commands* illustration as a guide when you change your password.

CallPilot voice prompts tell you which dialpad button to press for CallPilot options.

- The voice prompt plays immediately.
- Use the dialpad only to enter a command.
- If you know the corresponding dialpad number for the option you want, you can press it any time during the voice prompt.
- Press on the dialpad to interrupt a voice prompt.
- Press to return to the previous display prompt.
- If you do not choose an option after five seconds, the voice prompt replays the options.
- If you do not choose an option, the CallPilot session ends.



- Use the display button or the dialpad to enter a command.
- The voice prompt plays after a five second delay.
- When there are more than three options, or you do not know what the options are, wait for the voice prompt to state the options.
- Press **#** on the dialpad to interrupt a voice prompt.
- If you do not choose an option after five seconds, the voice prompt replays the options.




Make sure you are familiar with how to operate display telephones. Refer to your Telephone User Card.

From your display telephone
enter .


Follow the voice prompts or the button options on your display telephone to open your mailbox.

From an outside tone dial telephone, dial your company's telephone number.

When CallPilot answers, press **[*] [*]** (in Europe or Australia press **[8] [8]**) and follow the voice prompts to open your mailbox.



Play messages



Retrieving a deleted message

You can retrieve an deleted message if you are still in a CallPilot session. A deleted message remains in your mailbox until you end your current CallPilot session.

After you delete a message, the number of new or saved messages shown on the display decreases by one.


Press **PLAY** or

2

 to listen to your deleted messages.

When you play your deleted message, you have the option to save it. If you end the current session without saving the deleted message, it is permanently deleted from your mailbox.

Send messages



Leave a Message

Default code

☎

 9 8 0

Custom code

☎

 9 _ _

Press

☎

 9 8 0 on your display telephone to record and send a message directly to a mailbox without calling the extension number.

Open Mailbox

Default code

☎

 9 8 1

Custom code

☎

 9 _ _

Press

☎

 9 8 1 on your display telephone to access your mailbox menus.

Refer to the *Mailbox commands* illustration in this card to review your mailbox menus.

Call Forward

Default code

☎

 9 8 4

Custom code

☎

 9 _ _

Press

☎

 9 8 4 on your display telephone to forward calls directly to your mailbox.

To set up Call Forward remotely:

- Use a tone dial telephone to call your company’s telephone number. Wait for CallPilot to answer.
- While your greeting plays press

*

*

.
- Enter your mailbox number and password, then press

#

.
- Press

8

2

 and then press

3

.
- Press

1

 to enable or disable Call Forward.
- Press

1

 to enable or disable Call Display.
- Replace the handset to end the session.

Transfer

Default code

☎

 9 8 6

Custom code

☎

 9 _ _

Transfer a call from your display telephone directly to a mailbox.

To transfer a call to a mailbox from your telephone:

- Press

☎

 9 8 6 .
- Enter the mailbox number.
- Wait until the display shows **Call transferred** before you use other features.

Interrupt

Default code

☎

 9 8 7

Custom code

☎

 9 _ _

Intercepts a caller who is listening to your mailbox greeting or leaving a message.

You can program a feature code to a memory button with an indicator on your display telephone.

- If you program the Interrupt feature to a memory button:
- While a caller is listening to your mailbox greeting or leaving a message, the indicator (

▶

 or

▲

) flashes for the Interrupt button.

Press the Interrupt button to retrieve the call.

To program a memory button for the Interrupt feature:

- Press

☎

*

3

.
- The display shows **Program Features**.
- Press a memory button with an LCD indicator.
- Press

☎

 and then enter the feature code that you want to program.
- The display shows **Programmed**, then ends the session.

Call Record

Default code

☎

 9 8 9

Custom code

☎

 9 _ _

Record a telephone call and store the recorded call in your mailbox. Before you activate the Call Record feature, ask the parties on the call for permission to record it.

The System Administrator must enable the Call Record feature. In some areas Call Record is not available as it contravenes local laws.

Other features

For more information about all the CallPilot features, refer to the *CallPilot Reference Guide*. This guide explains in detail:

- Automated Attendant
- Alternate extensions
- Alternate language
- Call Screening
- Company Directory
- Message options
- Outbound Transfer
- Off-premise Message Notification
- Replying to a message
- Target Attendant
- Transferring calls