ShoreTel IP Phone 485g Quick Reference

PHONE OPERATION

Place Calls

Use the speakerphone or a headset



Use the Directory



Make a conference call



Make a call from History



Use the Intercom (through Directory)



Answer Calls

Answer a call



Send a call to voicemail



Divert an incoming call




+ Ext.

Adjust volume of handset, headset, or speakerphone

(+) to select

Answer call waiting (incoming call)

Press green blinking call appearance button or



Pick up a call for another extension

Interact with Calls

Mute a call



Place a call on hold

or press call appearance button

Take a call off hold

or press orange blinking call appearance button Hold

Transfer a call



Join calls

Park a call on another extension

Unpark a call



VOICEMAIL

main menu

Check visual voicemail



Log in from another extension


Log in to voicemail



EXTENSION ASSIGNMENT

Using Phone Interface

Assign ext. to Available or Anonymous phone



Unassign extension




Assign your ext. to an assigned phone



Using Voicemail System

Change ext. assignment

Unassign extension



CUSTOMIZE YOUR PHONE

Select a ringtone



Change call handling mode (CHM)



Change CHM and call forwarding



Change wallpaper







Change time zone





Log in or out of workgroup



TROUBLESHOOTING

View phone information




Reboot your phone



Note: For details about using the phone, see the ShoreTel IP Phone 485g User Guide.



ShoreTel IP Phone 485g Quick Reference



GUIDE TO LEDS

Your ShoreTel 485g IP phone provides color cues to help you determine call appearance status:

- Steady Green: Phone is in use (dialing or off hook)
- Blinking Green: Incoming call
- ightharpoonup Blinking Orange: On hold or call parked
- Steady Orange: Extension's call handling mode set to Do Not Disturb or phone in a No Service state. For BCA, the monitored extension is in use by another party but you can join the call
- Steady Red: Monitored extension is in use by other party (applies to BCA and Extension Monitor)

In Directory and History (details view), the following icons indicate a person's current phone status:



Available



Non-standard call-handling mode



On hold or has a call parked



Do not disturb



On a Call

GUIDE TO STATUS ICONS

Main Display



Unheard Voice Messages



Missed Calls



Logged in to Workgroup



Logged in to Workgroup, in Wrap-Up



Logged out of Workgroup



Standard call-handling mode



In a Meeting call-handling mode



Out of Office call-handling mode



Extended Absence call-handling



Custom call-handling mode

Call Appearance



Idle, On Hook



Off Hook, Dialing



Inactive / Do Not Disturb



Incoming Call



Connected Call



Connected Conference Call



On Hold Locally



On Hold Remotely



Speed Dial Extension



Speed Dial Extension with DND



Call is being recorded



Whisper mute is active

Monitored Extension



Monitored extension



Monitored extension and DND



Unheard messages



Unheard messages and DND



Connected call and incoming call



On a call



On a conference call



Monitored extension in a connected call and call answered locally



Monitored extension on hold and call answered locally



Monitored extension in a connected call with a call on hold

Visual Voicemail



Urgent



Message



Message with return receipt



OR Private message



Broadcast message



Broadcast message with return



Private broadcast message



Private broadcast message with return receipt



Private message with return