

October 06, 2021

John Harding Eagle Point School District #9 PO Box 548 Eagle Point, OR 97524 TEL: (541) 830-1240 FAX (541) 830-6375

RE: Shady Cove School Lead & Coppers

Order No.: 21091217

Dear John Harding:

Neilson Research Corporation received 5 sample(s) on 9/29/2021 for the analyses presented in the following report.

Neilson Research Corporation

Website: www.nrclabs.com

TEL: (541) 770-5678 FAX: (541) 770-2901

245 S Grape St Medford, OR 97501

The results relate only to the parameters tested or to the sample as received by the laboratory. This report shall not be reproduced except in full, without the written approval of Neilson Research Corporation. If you have any questions regarding these test results, please feel free to call.

Sincerely, Neilson Research Corporation

Tama Stimedeman

Tamra Schmedemann Senior Project Manager 245 S Grape St Medford, OR 97501



Original



### **Case Narrative**

WO#:21091217Date:10/6/2021

**CLIENT:**Eagle Point School District #9**Project:**Shady Cove School Lead & Coppers

The analyses were performed according to the guidelines in the Neilson Research Corporation Quality Assurance Program. This report contains analytical results for the sample(s) as received by the laboratory.

Neilson Research Corporation certifies that this report is in compliance with the requirements of NELAP. No unusual difficulties were experienced during analysis of this batch except as noted below or qualified with data flags on the reports.

Original



# **Analytical Report**

WO#: 21091217 Date Reported: 10/6/2021

CLIENT:	Eagle Point School District #9	<b>Collection Date:</b>	9/29/2021 6:59:00 AM
Lab ID:	21091217-01A	<b>Received Date:</b>	9/29/2021 9:26:00 AM
<b>Client Sample ID</b>	Bottle #03517	Matrix:	DRINKING WATER
Project:	Shady Cove School Lead & Coppers	PWS #:	41-91511
Sample Location:	PD Boys RR	Source ID:	DIST-A
Sample Address:		Sample Collector:	STEVE LAMBERT

Analyses	Code	Method	NELA Status	C	ual DF	RL Units	Date MCL Analyzed Analyst
Copper	1022	E200.8	A	0.0482	1	0.00206 mg/L	1.30 10/03/21 3:02 SJS
Lead	1030	E200.8	A	ND	1	0.000515 mg/L	0.0150 10/03/21 3:02 SJS

QUALIFIERS

\* Value exceeds Maximum Contaminant Level. Н Holding times for preparation or analysis exceeded

ND Not Detected at the Reporting Limit C1 Sample container temperature is out of limit as specified at testcode

MI Recovery outside comtrol limits due to Matrix Interference PL Permit Limit

Original



# **Analytical Report**

WO#: 21091217 Date Reported: 10/6/2021

CLIENT:	Eagle Point School District #9	<b>Collection Date:</b>	9/29/2021 6:45:00 AM
Lab ID:	21091217-02A	<b>Received Date:</b>	9/29/2021 9:26:00 AM
<b>Client Sample ID</b>	Bottle #65861	Matrix:	DRINKING WATER
Project:	Shady Cove School Lead & Coppers	PWS #:	41-91511
Sample Location:	Room 10	Source ID:	DIST-A
Sample Address:		Sample Collector:	STEVE LAMBERT

Analyses	Code	Method	NELAI Status	C.	ual DF	RL Units	Date MCL Analyzed Analyst
Copper	1022	E200.8	A	ND	1	0.00206 mg/L	1.30 10/03/21 3:06 SJS
Lead	1030	E200.8	A	ND	1	0.000515 mg/L	0.0150 10/03/21 3:06 SJS

QUALIFIERS

\* Value exceeds Maximum Contaminant Level. Н Holding times for preparation or analysis exceeded

ND Not Detected at the Reporting Limit C1 Sample container temperature is out of limit as specified at testcode

MI Recovery outside comtrol limits due to Matrix Interference PL Permit Limit

Original



# **Analytical Report**

WO#: 21091217 Date Reported: 10/6/2021

CLIENT:	Eagle Point School District #9	<b>Collection Date:</b>	9/29/2021 6:30:00 AM
Lab ID:	21091217-03A	<b>Received Date:</b>	9/29/2021 9:26:00 AM
<b>Client Sample ID</b>	Bottle #103731	Matrix:	DRINKING WATER
Project:	Shady Cove School Lead & Coppers	PWS #:	41-91511
Sample Location:	Staff Room	Source ID:	DIST-A
Sample Address:		Sample Collector:	STEVE LAMBERT

Analyses	Code	I Method	NELAI Status	C.	ual DF	RL Units	Date MCL Analyzed Ana	alyst
Copper Lead	1022 1030	E200.8 E200.8	A A	ND ND	1 1	0.00206 mg/L 0.000515 mg/L		SJS

QUALIFIERS

\* Value exceeds Maximum Contaminant Level. Н Holding times for preparation or analysis exceeded

ND Not Detected at the Reporting Limit C1 Sample container temperature is out of limit as specified at testcode

MI Recovery outside comtrol limits due to Matrix Interference PL Permit Limit

Original



# **Analytical Report**

WO#: 21091217 Date Reported: 10/6/2021

CLIENT:	Eagle Point School District #9	<b>Collection Date:</b>	9/29/2021 6:25:00 AM
Lab ID:	21091217-04A	<b>Received Date:</b>	9/29/2021 9:26:00 AM
<b>Client Sample ID</b>	Bottle #77322	Matrix:	DRINKING WATER
Project:	Shady Cove School Lead & Coppers	PWS #:	41-91511
Sample Location:	Room 1	Source ID:	DIST-A
Sample Address:		Sample Collector:	STEVE LAMBERT

Analyses	Code	Method	NELAI Status	<b>C</b>	ıal DF	<b>RL</b> Units	Date MCL Analyzed Anal	lyst
Copper	1022	E200.8	A	ND	1	0.00206 mg/L	1.30 10/03/21 3:15 SJ	-
Lead	1030	E200.8	A	0.0161 *	1	0.000515 mg/L	0.0150 10/03/21 3:15 SJ	

QUALIFIERS

\* Value exceeds Maximum Contaminant Level. Н Holding times for preparation or analysis exceeded

ND Not Detected at the Reporting Limit C1 Sample container temperature is out of limit as specified at testcode

MI Recovery outside comtrol limits due to Matrix Interference PL Permit Limit

Original



# **Analytical Report**

WO#: 21091217 Date Reported: 10/6/2021

CLIENT:	Eagle Point School District #9	<b>Collection Date:</b>	9/29/2021 6:49:00 AM
Lab ID:	21091217-05A	<b>Received Date:</b>	9/29/2021 9:26:00 AM
<b>Client Sample ID</b>	Bottle #99719	Matrix:	DRINKING WATER
Project:	Shady Cove School Lead & Coppers	PWS #:	41-91511
Sample Location:	MS Boys RR	Source ID:	DIST-A
Sample Address:		Sample Collector:	STEVE LAMBERT

Analyses	Code	Method	NELAI Status	C C	ual DF	RL Units	Date MCL Analyzed Analyst
Copper	1022	E200.8	A	0.136	1	0.00206 mg/L	1.30 10/03/21 3:19 SJS
Lead	1030	E200.8	A	ND	1	0.000515 mg/L	0.0150 10/03/21 3:19 SJS

QUALIFIERS

\* Value exceeds Maximum Contaminant Level. Н Holding times for preparation or analysis exceeded

ND Not Detected at the Reporting Limit C1 Sample container temperature is out of limit as specified at testcode MI Recovery outside comtrol limits due to Matrix Interference

PL Permit Limit

Original



Neilson Research Corporation 245 S Grape St Medford, OR 97501 TEL: (541) 770-5678 FAX: (541) 770-2901 Website: www.nrclabs.com

# QC SUMMARY REPORT

WO#: 21091217

06-Oct-21

Sample ID: <b>N</b> Client ID: <b>F</b>	MB-14320 PBW	SampType: MBLK Batch ID: 14320		de: ICPMS_20 No: E200.8	00.8 Units: mg/L E200.8		Prep Date: <b>9/30/2021</b> Analysis Date: <b>10/3/2021</b>				RunNo: <b>24967</b> SeqNo: <b>400618</b>		
Analyte		Result	PQL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual	
Copper Lead		ND ND	0.00206 0.000515										
Sample ID: L	_CS-14320	SampType: LCS	TestCo	de: ICPMS_20	00.8 Units: mg/L	Prep Date: 9/30/2021			21	RunNo: <b>24967</b>			
Client ID:	LCSW	Batch ID: 14320	Test	No: <b>E200.8</b>	E200.8		Analysis Date	e: 10/3/20	21	SeqNo: 400	0619		
Analyte		Result	PQL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual	
Copper		0.0968	0.00208	0.1000	0	96.8	85	115					
Lead		0.0975	0.000520	0.1000	0	97.5	85	115					
Sample ID: 2	21091176-01AMS	SampType: <b>MS</b>	TestCo	de: ICPMS_20	00.8 Units: mg/L		Prep Date	e: <b>9/30/20</b>	21	RunNo: 249	967		
Client ID:	BatchQC	Batch ID: 14320	Test	No: <b>E200.8</b>	E200.8		Analysis Date	e: 10/3/20	21	SeqNo: 400	0621		
Analyte		Result	PQL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual	
Copper		0.163	0.00208	0.1000	0.07817	85.3	70	130					
Lead		0.0916	0.000520	0.1000	0.001395	90.2	70	130					
Sample ID: 2	21091176-01AMSD	SampType: MSD	TestCo	de: ICPMS_20	00.8 Units: mg/L		Prep Date	e: <b>9/30/20</b>	21	RunNo: 249	967		
Client ID:	BatchQC	Batch ID: 14320	Test	No: <b>E200.8</b>	E200.8		Analysis Date	e: <b>10/3/20</b>	21	SeqNo: 400	0622		
Analyte		Result	PQL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual	
Copper		0.167	0.00208	0.1000	0.07817	89.2	70	130	0.1634	2.38	20		



## **QC SUMMARY REPORT**

WO#: 21091217

06-Oct-21

Client: Eagle Point School District #9

Project: Shady Cove School Lead & Coppers

TestCode: ICPMS\_200.8\_DW

Sample ID: 21091176-01AMSD Client ID: BatchQC	SampType: MSD Batch ID: 14320	TestCode: ICPMS_200.8 TestNo: E200.8		00.8 Units: mg/L E200.8	Prep Date: 9/30/2021 Analysis Date: 10/3/2021			RunNo: <b>24967</b> SeqNo: <b>400622</b>			
Analyte	Result	PQL	SPK value	SPK Ref Val	%REC	LowLimit	HighLimit	RPD Ref Val	%RPD	RPDLimit	Qual
Lead	0.0926	0.000520	0.1000	0.001395	91.2	70	130	0.09164	1.08	20	

**Qualifiers:** 

\* Value exceeds Maximum Contaminant Level.

C1 Sample container temperature is out of limit as specified at testcode

H Holding times for preparation or analysis exceede

Permit Limit

PL

MI Recovery outside comtrol limits due to Matrix Interference

RL Reporting Detection Limit

ND Not Detected at the Reporting Limit

NEILSON RESEARCH CORPORATION	i TEL: (541) 770-5678 F2	search Corporatio 245 S Grape Medford, OR 9750 AX: (541) 770-290 e: www.nrclabs.co		ole Log-In Check List
Client Name: EAGLEPTSCHOOL	Work Order Number:	21091217		RcptNo: 1
Logged by: Haylee Crowe	9/29/2021 9:26:00 AM		Hen la	
Completed By: Krizzle Calip	9/29/2021 5:32:22 PM		Shing the Cal	lig
Reviewed By: Dorie Maier	10/6/2021 4:03:09 PM		·Jon (	ME
Chain of Custody		_		_
1. Is Chain of Custody complete?		Yes 🖌	No 🗌	Not Present
2. How was the sample delivered?		<u>Client</u>		
<u>Log In</u>				
3. Coolers are present?		Yes 🗌	No 🗌	NA 🗹
4. Shipping container/cooler in good condition		Yes ⊻ Yes □	No 🗌 No 🗌	Not Present 🗹
Custody seals intact on shipping contair No. Seal Date		Signed By:		Not Present
5. Was an attempt made to cool the samp		Yes	No 🗌	NA 🗹
6. Were all samples received at a tempera	ture of >0° C to 6.0°C	Yes	No 🗌	NA 🗹
7. Sample(s) in proper container(s)?		Yes 🗸	No 🗌	
8. Sufficient sample volume for indicated to	est(s)?	Yes 🖌	No	
9. Are samples (except VOA and ONG) pr		Yes 🖌	No 🗌	
10. Was preservative added to bottles?		Yes 🖌	No 🗌	NA 🗌
				HNO3 pH<2
11. Is the headspace in the VOA vials less t	han 1/4 inch or 6 mm?	Yes 🗌	No	No VOA Vials 🖌
12. Were any sample containers received b	roken?	Yes	No 🔽	
13. Does paperwork match bottle labels?	A	Yes 🖌	No	
(Note discrepancies on chain of custody 14. Are matrices correctly identified on Chai		Yes 🔽	No 🗌	
15. Is it clear what analyses were requested		Yes 🗹		
16. Were all holding times able to be met?		Yes 🗹	No 🗌	
(If no, notify customer for authorization.)				
<b>Special Handling (if applicable)</b> 17. Was client notified of all discrepancies w	with this order?	Yes	No 🗌	NA 🖌
Person Notified:	Date			
By Whom:	Via:	eMail Pr	none 🗌 Fax	In Person
Regarding:				
Client Instructions:				
18. Additional remarks:	D 01001017 044	in color		
The sample submitted for sample I Cooler Information	L 21091217-04A Was beige			
Cooler No Temp <sup>o</sup> C Condit	ion Seal Intact Seal	No Seal Da	te Signed	By
	ion Jean mact Jean	ito Jeai Da	ale olyried	<u>Uy</u>

		Neilson	<b>R</b>	ESEARCH	Corp	ORA	TION
LAB	NRC Sample Number Received By:	<u>, 21091217</u>	-(	AIC	Date Received Time Receive		29,2) : <u>26</u> am/pm

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your State under the Lead and Copper Rule, and is being accomplished through collaboration between the public water system and their consumers (e.g. residents).

Collect samples from a tap that has not been used for at least 6 hours. To ensure the water has not been used for at least 6 hours, the best time to collect samples is either early in the morning or in the evening upon returning from work. Be sure to use a kitchen or bathroom cold water tap that has been used for drinking water consumption in the past few weeks. The collection procedure is described below.

1. Prior arrangements will be made with you to coordinate the sample collection. Dates will be set for sample kit delivery and pick-up by water system staff.

2. There must be a minimum of 6 hours during which there is no water used from the tap where the sample will be collected and any taps adjacent or close to that tap. Either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist. **Do not** intentionally flush the water line before the start of the 6 hour period.

3. Use a kitchen or bathroom cold-water faucet for sampling. If you have water softeners on your kitchen taps, collect your sample from the bathroom tap that is not attached to a water softener, or a point of use filter, if possible. *Do not* remove the aerator prior to sampling. Place the opened sample bottle below the faucet and open the cold water tap as you would do to fill a glass of water. Fill the sample bottle to the line marked "1000-mL" and turnoff the water.

4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.

5. If any plumbing repairs or replacements have been done in the home since the previous sampling event, note this information on the back of this form. Also if your sample was collected from a tap with a water softener, note this as well.

6. Place the sample kit in the location the kit was delivered to so that water system staff may pick up the sample kit.

Call	at		if you have any questior	ns.
	TO BE COMPLET	ED BY RESIDENT	Q 75	
Water was last used:	Time 6:00 :	and/pm D	ate <u>7 128 1</u> 2	-/
Sample was collected:	Time_6 : 5	Tanyon D	ate <u>7 129 12</u>	-/_
Name of Water System:	Shady Coves	School	PWS ID 41	
Sample Collected by: 🗧	steven Laune	pert	Bottle # 🚺 🕑	3517
Address: 100 Cle	veland She	rdy Cove	Space #	
Faucet Location: (e.g. Kitcl	hen Faucet)PD_E	BOYTRR		
I have read the ab	pove directions and have tak	en a tap sample in ac	ccordance with these dire	ctions.
Signature	Ton Page	Date	9-29-21	

Lab Sample ID Date Received Time Received Received By

# Lead & Copper First Draw Sample Collection Procedures

These samples are being collected to determine lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your state, and is being accomplished through the cooperation of homeowners and residents.

Collect all water samples before the facility opens and before any water is used. Ideally, the water should sit in the pipes unused for at least 6 hours but not more than 18 hours before a sample is taken. Make sure that no water is withdrawn from the taps or fountains from which the samples are to be collected prior to their sampling.

Unless specifically directed to do so, do not collect samples in the morning after vacations, weekends, or holidays because the water will have remained stagnant for too long and would not represent the water used for drinking during most of the days of the week.

- 1. Prior arrangement will be made with customer to coordinate the sample collection event. Dates will be set for a sample kit delivery and pick-up by the water department staff.
- 2. A kitchen or bathroom cold water faucet is to be used for sampling. Place the open sample bottle below the faucet and gently open the cold water tap. Fill the sample bottle to the neck and turn off the water.
- 3. Tightly cap the sample bottle. Please carefully complete this form.
- 4. IF ANY PLUMBING REPAIRS OR REPLACEMENT HAVE BEEN DONE IN THE HOME SINCE THE PREVIOUS SAMPLING EVENT, NOTE THIS INFORMATION ON THIS FORM BELOW.
- 5. Place the sample with form attached outside of the residence in the location of the delivery for pick up.
- 6. Results from this monitoring effort will be provided to participating customers when reports are generated for the State unless excessive lead and/or copper levels are found. In those cases, immediate notification will be provided, usually 10 working days from the time of sample collection.

If you have any questions please call:

TO BE COMPLETED BY RE	SIDENT				
Water was last used:	Time_600 (am/pm) Date 9-22-21				
Sample was collected:	Time <u>[: 45 (am/pm)</u> Date <u>9-29-21</u>				
Name of Water System <u>Sha</u>	ady Cove School PWS ID 41-				
Sample Collected by Ste	ve Lambert Bottle # 65861				
Address 37 Shoolhouse In Shady Grespace #					
Faucet Location	200m 10				
Note any plumbing repairs or replacements made since last sampling event:					
I have read the above direction Signature	is any have taken a tap sample in accordance with these directions. Date $9 - 29 - 21$				

			EARCH CORPORATION mental Testing Laboratory	
LAB	NRC Sample Number:_ Received By:	<u>21091217-037</u>	A Date Received: <u>9,29,0</u> Time Received: <u>9</u> : <u>96</u>	<mark>2  </mark> .am/pm

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your State under the Lead and Copper Rule, and is being accomplished through collaboration between the public water system and their consumers (e.g. residents).

Collect samples from a tap that has not been used for at least 6 hours. To ensure the water has not been used for at least 6 hours, the best time to collect samples is either early in the morning or in the evening upon returning from work. Be sure to use a kitchen or bathroom cold water tap that has been used for drinking water consumption in the past few weeks. The collection procedure is described below.

1. Prior arrangements will be made with you to coordinate the sample collection. Dates will be set for sample kit delivery and pick-up by water system staff.

2. There must be a minimum of 6 hours during which there is no water used from the tap where the sample will be collected and any taps adjacent or close to that tap. Either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist. **Do not** intentionally flush the water line before the start of the 6 hour period.

3. Use a kitchen or bathroom cold-water faucet for sampling. If you have water softeners on your kitchen taps, collect your sample from the bathroom tap that is not attached to a water softener, or a point of use filter, if possible. **Do not** remove the aerator prior to sampling. Place the opened sample bottle below the faucet and open the cold water tap as you would do to fill a glass of water. Fill the sample bottle to the line marked "1000-mL" and turnoff the water.

4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.

5. If any plumbing repairs or replacements have been done in the home since the previous sampling event, note this information on the back of this form. Also if your sample was collected from a tap with a water softener, note this as well.

6. Place the sample kit in the location the kit was delivered to so that water system staff may pick up the sample kit.

Call	at		if you have any questions.
	TO BE COMPLETI	ED BY RESIDENT	IT C STA
Water was last used:	Time:	am/pm	Date 7 128 1 21
Sample was collected:	Time:3		Date <u>7 129 12 (</u>
Name of Water System: _	Shady Care S	chool	PWS ID 41
Sample Collected by:	Steven Land	et	Bottle # 103731
Address: 37 5ho	D) house In		Space #
Faucet Location: (e.g. Kite	chen Faucet)	ff roor	$\gamma$
I have read the a	www.edirections.and have tak	en a tap sample i	in accordance with these directions.
Signature	the age 13	3 pf 15	ate 9-29-21

			<b>RESEARCH</b> Environmental Testing	<b>CORPORATION</b> Laboratory
LAB	NRC Sample Number: Received By:+++	21091217 -	CUA	Date Received: <u><u> </u></u>

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your State under the Lead and Copper Rule, and is being accomplished through collaboration between the public water system and their consumers (e.g. residents).

Collect samples from a tap that has not been used for at least 6 hours. To ensure the water has not been used for at least 6 hours, the best time to collect samples is either early in the morning or in the evening upon returning from work. Be sure to use a kitchen or bathroom cold water tap that has been used for drinking water consumption in the past few weeks. The collection procedure is described below.

1. Prior arrangements will be made with you to coordinate the sample collection. Dates will be set for sample kit delivery and pick-up by water system staff.

2. There must be a minimum of 6 hours during which there is no water used from the tap where the sample will be collected and any taps adjacent or close to that tap. Either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist. **Do not** intentionally flush the water line before the start of the 6 hour period.

3. Use a kitchen or bathroom cold-water faucet for sampling. If you have water softeners on your kitchen taps, collect your sample from the bathroom tap that is not attached to a water softener, or a point of use filter, if possible. **Do not** remove the aerator prior to sampling. Place the opened sample bottle below the faucet and open the cold water tap as you would do to fill a glass of water. Fill the sample bottle to the line marked"1000-mL" and turnoff the water.

4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.

5. If any plumbing repairs or replacements have been done in the home since the previous sampling event, note this information on the back of this form. Also if your sample was collected from a tap with a water softener, note this as well.

6. Place the sample kit in the location the kit was delivered to so that water system staff may pick up the sample kit.

Call	at	if y	ou have any questions.
	TO BE COMPLET	ED BY RESIDENT	0.22
Water was last used:	Time :	2 am/pm Date	9 128 121
Sample was collected:	Time_6 : 24	5 (am/pm Date	9 129 121
Name of Water System:	Shady Cove	School	PWS ID 41
Sample Collected by:	Steve Salan	Noert	Bottle # 77322
Address: 37 Sh	oil house In	Shady Cove	Space #
Faucet Location: (e.g. Ki	tchen Faucet)R	NOOM	
I have read the	above directions and have tal	ken a tap sample in accor	rdance with these directions.
Signature_	Man Joiner	14 of 15 Date	-2921

	NEILSON	RESEARCH Environmental Testing	<b>CORPORATION</b> Laboratory
LAB	NRC Sample Number: 21091217 Received By:	-0579	Date Received: <u>9,29,21</u> Time Received: <u>9</u> : <u>26</u> am/pm

These samples are being collected to determine the lead and copper levels in your tap water. This sampling effort is required by the U.S. Environmental Protection Agency and your State under the Lead and Copper Rule, and is being accomplished through collaboration between the public water system and their consumers (e.g. residents).

Collect samples from a tap that has not been used for at least 6 hours. To ensure the water has not been used for at least 6 hours, the best time to collect samples is either early in the morning or in the evening upon returning from work. Be sure to use a kitchen or bathroom cold water tap that has been used for drinking water consumption in the past few weeks. The collection procedure is described below.

1. Prior arrangements will be made with you to coordinate the sample collection. Dates will be set for sample kit delivery and pick-up by water system staff.

2. There must be a minimum of 6 hours during which there is no water used from the tap where the sample will be collected and any taps adjacent or close to that tap. Either early mornings or evenings upon returning home are the best sampling times to ensure that the necessary stagnant water conditions exist. **Do not** intentionally flush the water line before the start of the 6 hour period.

3. Use a kitchen or bathroom cold-water faucet for sampling. If you have water softeners on your kitchen taps, collect your sample from the bathroom tap that is not attached to a water softener, or a point of use filter, if possible. **Do not** remove the aerator prior to sampling. Place the opened sample bottle below the faucet and open the cold water tap as you would do to fill a glass of water. Fill the sample bottle to the line marked "1000-mL" and turnoff the water.

4. Tightly cap the sample bottle and place in the sample kit provided. Please review the sample kit label at this time to ensure that all information contained on the label is correct.

5. If any plumbing repairs or replacements have been done in the home since the previous sampling event, note this information on the back of this form. Also if your sample was collected from a tap with a water softener, note this as well.

6. Place the sample kit in the location the kit was delivered to so that water system staff may pick up the sample kit.

Call	at		if you have any questions.
	TO BE COMPI	ETED BY RESIDEN	NT
Water was last used:	Time_6_:_	∞ am/pm	Date <u> 128121</u>
Sample was collected:	Time_6:	49 (an/pm	Date 9 129121
Name of Water System:	MSIBO	YS RR	PWS ID 41
Sample Collected by:	Steve/am	bert	Bottle # 99719
Address: 100 deve	eland Shad	y Corto	Space #
Faucet Location: (e.g. Kitc	hen Faucet)_MS_	Bays R	1
I have read the a	boye directions and have	taken a tap sample	e in accordance with these directions.
Signature	The tombe	UT D	Date 7-29-2