



# Refresh Chromebook during testing or general classroom use.

Sometimes a chromebook can get corrupt on an extension used with a program or need to renew its network connectivity (usually indicated by grey screen, blank page, weak wifi or failure to connect. A simple refresh will help solve issues.

## Refresh Google Chromebook.

1. Press **Refresh+Power** on your keyboard.  **Refresh**  **+ Power.**
2. Power the unit back on.
3. Make sure connected to HLMAIN.
4. Try your Testing App or logging in if using classroom.
5. **If this not not work repeat Step 1** and then let it connect to its preferred network.
6. 95 percent of the time this works if not I will need to wipe the chromebook.